### Using ES820 with the integrated GPS feature

#### Do you know this challenge?

You are a calibration engineer and you are interested in receiving some information regarding your trip as the altitude, longitude, latitude etc. You would also like to have them synchronized with ECU and environmental data, and recorded in the same file.

### Our Solution – GPS signals acquisition via USB GPS device

Within INCA you are able to connect a GPS device: like the other devices it can be found in the Hardware Configuration and its signals (e.g. Longitude, Latitude, Date, Time, Altitude...) can be added in the INCA Experiment Environment. Then, the whole can be exported and loaded onto the ES820.

Regarding the post-processing, the data may be used in MDA in "Map View", so that also the map of the trip is shown and synchronized with all other information.

#### How does it work? Example: how to use the GPS device with the ES820

First of all, the GPS drivers must be installed onto the DriveRecorder. Please note that the drivers of some GPS devices (as e.g. NL-442U) are already included in the installation of the SP7 of ES820 and therefore there is no need to install them.

Connect the Ethernet cable CBE250 to the HOST Port of the ES820 and to your PC, and access the DriveRecorder via MS Remote Desktop Connection:

- On your PC, from the Start Menu launch Remote Desktop Connection tool (Fig.1)
- Enter the IP address, select the user, and then enter the corresponding password





Once logged into the ES820, start the **device manager** (e.g. *Start -> Computer -> Manage*) as on a normal PC:

- Physically plug the GPS mouse in a compatible USB port (3.0 on the right or 2.0 in the left) (Fig.2)
- Check the driver status and note to which COM Port the GPS mouse has been assigned (Fig.3)

If necessary, install the driver (for many devices it is not necessary!):

- Copy the installation file to the ES820 and run it there
- From the DRConfigurator, select *Tool -> Persist Current System Configuration*
- The ES820 will perform a couple of memory cycles



Fig.2



Fig. 3



After that, you have to configure the INCA .exp file with some GPS device signals on your PC, and export it to the DriveRecorder.

• Add *GPS\_System* from the list of devices

 Select the right COM Port assigned by ES820 in the tab GPS\_Device Parameters and press Apply

Please open INCA and go to the Hardware Configuration page (Fig.4)

File Hardware Device Channels View MCE ?   I Hardware devices Image: Channels 4 GPS_Device Parameters   HWK Workspace.dr GPS_Device1   Image: GPS_Device1 GPS_Device1   Image: GPS_Device1 GPS_Device1   Image: GPS_Device1 GPS_Device1   Device inactive (Status not detected period of the connected period period of the connected period per	Hardware: >Workspace_dr< Experiment: >Experiment_GPS_dr< OFFLINE MODE							
Image: Construction of the second	File Hardware Device Channels View MCE ?							
1 Hardware devices       2 Parameters       3 Channels       4 GPS_Device Parameters         GPS_System:1       GPS_Device:1       GPS_Parameters       GOM Port       COM6         Baudrate       4 800       Baudrate       4 800       Baudrate       6 800         Recording Parameters       GPX recording files       C:ETASDatalINCA7:21Measure          Name base for GPX files       GPS_measure          Auto Increment       On       On	🔍 🕘 🍣 🚺 🕂 🗶 🛛	🕂 🗶 🌮 🕮 🗱   🏧 🅵   🕨 🔳   🍕   🐟						
Com Port COM6 Baudrate 4800 Becording Parameters GPX recording files C:\ETASData\INCA7.2\Measure Name base for GPX files GPS_measure Auto Increment On	1 Hardware devices HWK Workspace_dr GPS_System:1	e_dr GPS_Device %1 GPS_Parameters						
Baudrate     4800       Recording Parameters     GPX recording enabled       GPX recording files     C:\ETASData\INCA7.2\Measure       Name base for GPX files     GPS_measure       Auto Increment     On	🚔 GPS_Device:1	Com Port	COM6					
Pevice inactive (Status not detect Device not connected		Baudrate	4800					
GPX recording enabled     Off       Path for GPX recording files     C:\ETASData\INCA7.2\Measure       Name base for GPX files     GPS_measure       Auto Increment     On		Recording Parameters						
Path for GPX recording files     C:\ETASData\INCA7.2\Measure       Name base for GPX files     GPS_measure       Auto Increment     On		GPX recording enabled	Off					
Name base for GPX files     GPS_measure       Auto Increment     On		Path for GPX recording files	C:\ETASData\INCA7.2\Measure					
Auto Increment On Auto Increment		Name base for GPX files	GPS_measure					
Device inactive (Status not detec Device not connected		Auto Increment	On					
Device inactive (Status not detec								
- Device not connected	🚔 Device inactive (Status not detec		*					
	🚔 Device not connected		<b>v</b>					
	🖶 Device connected							
O No init. or no access	😑 No init. or no access							
P HW status can not be detected Reset	HW status can not be detected	Apply	Reset					

Fig.4

In the Experiment Environment, do not forget to add the relevant signals from GPS!

Then export the DriveRecorder .exp file by *Hardware -> Drive Recorder -> Export...* (Fig.5).

🕎 Ex	🖾 Experiment: >Experiment_GPS_dr< Hardware: >Workspace_dr<						
Experi	iment Edit View Variables	Measurement	Hardware Dataset Components E-Targe	t DBC Generator ODX In	nstrument Window ?		
2	🛄 Measure Window [1]		✓ ECU calibration access Initialize hardware	Ctrl+L F3			
6	Altitude	- [meter	And Hardware status	Alt+F3			
	Date	- [date]	 ≇≣ <u>M</u> anage memory pages	Shift+F8			
	Latitude	- [degre	Switch Between Working/Reference Page	F8			
	Latitude_hemisphere	- 0	Ac <u>t</u> ive device group	Ctrl+2			
	Longitude	- [degre	Manage store bits				
	Longitude_hemisphere	- 0	Check <u>F</u> irmware Status				
ţţ	Receiver_Status	- 0	Update Firmware				
	Satellites	- []	Drive Recorder	Optimize	ed Export		
+0)	Speed	- [km/h]	]	Export Open Dri	ive Recorder Configurator		
	UTC_Time	- [time]					
»							
	Measurement stopped				Max. buffer level: 0%		

In the DRConfigurator Tool:

- create a new Recording Job
- o double-click or drag&drop the INCA export file to the right side of the page
- o set the Start condition as Automeasure (Fig.6)
- File -> Apply the recording job to the DriveRecorder

Your ES820 is ready and at the next start will be able to record GPS data automatically as the satellite is reached.

The recorded GPS data can be read within MDA in a "Map View" window.

🐟 Administrator: DriveRecorder Configurator*					
File Edit Tools Run Help					
🗎 📽 🗠 🖬 🕼 🗇 🕷 🗵 🐟 🖒 💠 🕇	🗶 🕆 🕂   🕨 🕪 🔝 🔜 📙				
Active Recording Jobs	Name				
	GPS				
GPS (a)	Start condition	Automeasure			
	GPS_dr.exp	Internal storage, As INCA, Wait for devices			
	Recorder settings				
	Experiment name	GPS_dr.exp			
	Wait for devices	Enable			
	Storage area	Internal storage ○ External storage E: ▼			
INCA Exports	ECU page	As INCA 🔹			
Local PC O DriveRecorder	Diagnostic events				
GPS_dr.exp					
DemoCalcSignal.exp					
	Stop condition	After experiment stops automatically			
<					
🍑 Disconnected   🤽 Changes in current Recordin	g Configuration				

Fig.6

#### **Tools used**

- DriveRecorder ConfiguratorTool 7.2.7.125
- o ES820 SP7 (7.2.7.128)
- o INCA 7.2.7
- o MDA 7.2.7

#### Your ETAS Contact

Chiara Fiorini Tel. +49 711 3423 - 2996 Email: chiara.fiorini@etas.com





Public | ETAS GmbH | 2018 4 © ETAS GmbH 2018. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of applications for industrial property rights.