

## ES930: How to control the rotation direction of a DC motor using the ES930?



### Question

- How can I turn the rotation direction of a DC motor?
- How can I use the Power Stages of the ES930 to reverse external provided power (polarity reversal)?



### Answer

- You can control the rotation direction of a DC motor within reversing the provided power to it (polarity reversal).
- To achieve this you use the Power Stages of the ES930 which can be controlled within Digital Out of the ES930.

### Step-by-step guide

Prerequisites:

- ES910
- ES930
- CBAV422 Cable

Hardware Connections:

- **ES910: "PC Sync"-Port** => PC "Ethernet"-Port
- **ES910: "IO (Daisychain)"-Port** => ES930 "In (Daisychain)"-Port
- **ES930: "PS"-Port** => cable "CBAV422"

Please see figure: "ES930, used Ports"




Figure: "ES930, used Ports"

- **Cable "CBAV422" (PS\_GND, PS\_UBAT)** => to external Power (Remark: PS excepts external Power from 7V to 34V)
- **Cable "CBAV422" (PS\_CH1 - white, PS\_CH2 - brown)** => Voltage measuring device, or motor you like to control

Please see figure: "CBAV422.1; used cables"

*Assignment of the CBAV422.1 cable when used at the "PS" connection*

HD-SUBD Pin	Signal	Open cable end Color	
1, 10	PS_CH1	white	Page C
2, 11	PS_CH2	brown	
3, 12	PS_CH3	green	
4, 13	PS_CH4	yellow	
5, 14	PS_CH5	gray	
6, 15	PS_CH6	pink	
19, 20, 21,	PS_UBAT	blue	Page B
22, 23, 24,	PS_UBAT	red	
25	PS_UBAT	black	
	PS_UBAT	violet	
	PS_UBAT	gray/pink	
7, 8, 9, 16,	PS_GND	red/blue	Page D
17, 18, 26	PS_GND	white/green	
	PS_GND	brown/green	
	PS_GND	white/yellow	
	PS_GND	yellow/brown	
Housing		Shield	

Figure: "CBAV422.1; used cables"

We use Power Stage "Half Bridge 1 / 2". To get control of the Power Stage (PS) for the ES930 you need to make the Daisychain Configuration for the Digital Out "DO" for in the following way:

- Select ES930\_DO1\_CH1 and select in the column "Power Stage" "Half Bridge 1".  
Remark: Optional you can select in the column "LED" the led "U1" for controlling the activity (it's just an visual indicator for the signal)
- Select ES930\_DO1\_CH2 and select in the column "Power Stage" "Half Bridge 2".  
Optional you can select in the column "LED" the led "U2" for controlling the activity.
- Select ES930\_PS1\_CH1\_2\_Enable.  
Comment: Before you can do so you need to assign the half bridges to CH1 and CH2.


Please see figure: "ES930, Daisychain configuration for Digital Out (DO)"

No.	Settings	Sel.	HW Channel	Active State	Mode	Name	Update Mode	Alignment	LED	Power Stage	Output	Active Time	Period Time	Units	Comment
1		<input type="checkbox"/>		High	Digital Out	ES930_DO1_CH1	Individual	n/a	U1	Half Bridge 1	inactive	n/a	n/a	bit	
2		<input checked="" type="checkbox"/>	CH1	n/a	n/a	ES930_DO1_CH1_PeriodTime	n/a	n/a	n/a	n/a	n/a	n/a	n/a	msec	
3		<input type="checkbox"/>		n/a	n/a	ES930_DO1_CH1_Enable	n/a	n/a	n/a	n/a	Enabled	n/a	n/a	bit	
4		<input checked="" type="checkbox"/>	CH2	High	Digital Out	ES930_DO1_CH2	Individual	n/a	U2	Half Bridge 2	inactive	n/a	n/a	bit	
5		<input type="checkbox"/>		n/a	n/a	ES930_DO1_CH2_PeriodTime	n/a	n/a	n/a	n/a	n/a	n/a	n/a	msec	
6		<input type="checkbox"/>		n/a	n/a	ES930_DO1_CH2_Enable	n/a	n/a	n/a	n/a	Enabled	n/a	n/a	bit	
7		<input type="checkbox"/>	CH3	High	Digital Out	ES930_DO1_CH3	Individual	n/a	None	None	inactive	n/a	n/a	bit	
8		<input type="checkbox"/>		n/a	n/a	ES930_DO1_CH3_PeriodTime	n/a	n/a	n/a	n/a	n/a	n/a	n/a	msec	
9		<input type="checkbox"/>		n/a	n/a	ES930_DO1_CH3_Enable	n/a	n/a	n/a	n/a	Disabled	n/a	n/a	bit	
10		<input type="checkbox"/>	CH4	High	Digital Out	ES930_DO1_CH4	Individual	n/a	None	None	inactive	n/a	n/a	bit	
11		<input type="checkbox"/>		n/a	n/a	ES930_DO1_CH4_PeriodTime	n/a	n/a	n/a	n/a	n/a	n/a	n/a	msec	
12		<input type="checkbox"/>		n/a	n/a	ES930_DO1_CH4_Enable	n/a	n/a	n/a	n/a	Disabled	n/a	n/a	bit	
13		<input type="checkbox"/>	CH5	High	Digital Out	ES930_DO1_CH5	Individual	n/a	None	None	inactive	n/a	n/a	bit	
14		<input type="checkbox"/>		n/a	n/a	ES930_DO1_CH5_PeriodTime	n/a	n/a	n/a	n/a	n/a	n/a	n/a	msec	
15		<input type="checkbox"/>		n/a	n/a	ES930_DO1_CH5_Enable	n/a	n/a	n/a	n/a	Disabled	n/a	n/a	bit	
16		<input type="checkbox"/>		n/a	n/a	ES930_DO1_CH6_PeriodTime	n/a	n/a	n/a	n/a	inactive	n/a	n/a	bit	
17		<input type="checkbox"/>		n/a	n/a	ES930_DO1_CH6_Enable	n/a	n/a	n/a	n/a	n/a	n/a	n/a	msec	
18		<input type="checkbox"/>	CH1-CH2	n/a	n/a	ES930_PS1_CH1_2_Enable	n/a	n/a	n/a	n/a	Enabled	n/a	n/a	bit	
19		<input type="checkbox"/>	CH3-CH4	n/a	n/a	ES930_PS1_CH3_4_Enable	n/a	n/a	n/a	n/a	Disabled	n/a	n/a	bit	
20		<input type="checkbox"/>	CH5-CH6	n/a	n/a	ES930_PS1_CH5_6_Enable	n/a	n/a	n/a	n/a	Disabled	n/a	n/a	bit	
21		<input type="checkbox"/>		n/a	n/a	ES930_PS1_CH7_8_Enable	n/a	n/a	n/a	n/a	Disabled	n/a	n/a	bit	

Figure: "ES930, Daisychain configuration for Digital Out (DO)"

That's it!

This Daisychain Configuration will be used later on in your Hardware Configuration. You will have the following signals appearing there:



These signals can be used for calibration now (we don't show here how to setup the experiment environment for calibrating signals)

"ES930\_PS1\_CH1\_2\_Enable" is used to activate / deactivate the control of the Power Stage, if it is enabled you can use "ES930\_DO\_CH1" and "ES930\_DO\_CH2" to control the Power Stage.

The Table below shows how the output voltage behaves within different calibrations for: ES930\_PS1\_CH1\_2\_Enable, ES930\_DO\_CH1, ES930\_DO\_CH2

ES930_PS1_CH1_2_Enable	ES930_DO_CH1	ES930_DO_CH2	Output Voltage (measured within white / brown of connected PS cable)
1	0	0	0
1	0	1	- (external provided power)
1	1	0	+ (external provided power)
1	1	1	0
0	0	0	0
0	0	1	0
0	1	0	0
0	1	1	0

Table: "Combinations for ES930\_PS1\_CH1\_2\_Enable, ES930\_DO\_CH1, ES930\_DO\_CH2"



Do you still have questions?

- You will find **further FAQ articles** on the ETAS homepage: [www.etas.com/en/faq](http://www.etas.com/en/faq)
- **Movies** corresponding to FAQ articles can be found on the [ETAS YouTube channel](#)
- Please feel free to contact our Support Center, if you have further questions.
- Here you can find all information: <http://www.etas.com/en/hotlines.php>

This information (here referred to as „FAQ“) is provided without any (express or implied) warranty, guarantee or commitment regarding completeness or accuracy. Except in cases of willful damage, ETAS shall not be liable for losses and damages which may occur or result from the use of this information (including indirect, special or consequential damages).