

**Question:**

- Which ASCET version works with which EHOOKS version?
- Which ASCET version is required for which EHOOKS version?
- Which EHOOKS version is required for which ASCET version?

**Answer:**

	ehTools**	ASCET V7.3.0*	ASCET V6.4.3*	ASCET V6.4.2*	ASCET V6.4.1*	ASCET V6.3.0 SE Hotfix 1	ASCET V6.3.0	ASCET V6.2.1
EHOOKS V4.2.0*	EH420	yes	yes	no	no	no	no	no
EHOOKS V4.1.3*	EH413	no	no	yes	no	no	no	no
EHOOKS V4.1.2*	EH412	no	no	no	yes	no	no	no
EHOOKS V4.0.4	EH404	no	no	yes	yes	yes	no	yes
EHOOKS V4.0.3	EH403	no	no	yes	yes	yes	no	yes
EHOOKS V4.0.2	EH402	no	no	yes	yes	yes	no	yes
EHOOKS V4.0.1	EH401	no	no	yes	yes	yes	no	yes
EHOOKS V4.0.0	EH400	no	no	yes	yes	yes	no	yes

	ehTools**	ASCET V7.3.0*	ASCET V6.4.3*	ASCET V6.4.2*	ASCET V6.4.1*	ASCET V6.3.0 SE Hotfix 1	ASCET V6.3.0	ASCET V6.2.1
EHOOKS V3.1.5	EH315	no	no	yes	yes	yes	yes	yes
EHOOKS V3.1.4	EH314	no	no	yes	yes	yes	yes	yes
EHOOKS V3.1.3	EH313	no	no	yes	yes	yes	yes	yes
EHOOKS V3.1.2	EH312	no	no	yes	yes	yes	yes	yes
EHOOKS V3.1.1	EH311	no	no	yes	yes	yes	yes	yes
EHOOKS V3.1.0	EH310	no	no	yes	yes	yes	yes	yes
EHOOKS V3.0	EH300	no	no	yes	yes	yes	yes	yes



### Additional information:

\* Please note: From EHOOKS 4.1.x and ASCET 6.4.x, only the most recent version of EHOOKS 4.1.x available at the time of the ASCET 6.4.x release is supported.

- This means:
  - We did not test all possible combinations - only the ones marked with " **yes** "
  - We strongly recommend to not use any other combinations as the ones marked with " **yes** "
    - Other combinations may show surprising behavior and are therefore not recommended
    - Even if they seem to work they most probably will not provide the full set of features

# 1 \*\*ehTools

- In order to configure which EHOOKS version is used with ASCET:
  1. Edit <ASCET\_installation\_directory>\target\trg\_ehooks\target.ini
  2. Add following line (if it does not already exist): **ehTools=<ehTools>**
  3. Replace <ehTools> in this line with the according string provided in column **ehTools\*** in the table above
- Example: In order to use EHOOKS V4.0 with ASCET V6.2.1 add following entry to file ..\ETAS\ASCET6.2\target\trg\_ehooks\target.ini

**ehTools = EH400**



## In case of further questions:

---

- You will find further FAQ here: [www.etas.com/en/faq](http://www.etas.com/en/faq)
- Please feel free to contact our Support Center, if you have further questions.
- Here you can find all information: <http://www.etas.com/en/hotlines.php>

This information (here referred to as „FAQ“) is provided without any (express or implied) warranty, guarantee or commitment regarding completeness or accuracy. Except in cases of willful damage, ETAS shall not be liable for losses and damages which may occur or result from the use of this information (including indirect, special or consequential damages).