


## EHOOKS not available in ASCET




## Question

- I installed a new version of ASCET but there is no EHOOKS available under **Project Properties** → **Build** → **Target**
- In ASCET → Menu bar → Tools → Options → Targets



- There are several targets listed, for example **ES1130**, **ES910**, **Prototyping** but not **EHOOKS**


- The same in **Project Properties** → **Build** → **Target**: No EHOOKS available






Answer


- Install ASCET-SE-EHOOKS
- Start ASCET-SE installation either from **ETAS Product Installation** menu:



- or manually from file explorer: **ASCET-SE.exe**




- Walk through the installation program:
  - Make appropriate settings and click **Next >** button until you reach the page **Select targets to be installed**
  - On page **Select targets to be installed**: Check **EHOOKS-enabled ECU**




- Finish installation process

- Afterwards: Under **Tools** → **Options** → **Targets**: EHOOKS is available



- And under: **Project Properties** → **Build** → **Target**: EHOOKS is available



Do you still have questions?

- You will find **further FAQ articles** on the ETAS homepage: [www.etas.com/en/faq](http://www.etas.com/en/faq)
- **Movies** corresponding to FAQ articles can be found on the [ETAS YouTube channel](#)
- Please feel free to contact our Support Center, if you have further questions.
- Here you can find all information: <http://www.etas.com/en/hotlines.php>

This information (here referred to as „FAQ“) is provided without any (express or implied) warranty, guarantee or commitment regarding completeness or accuracy. Except in cases of willful damage, ETAS shall not be liable for losses and damages which may occur or result from the use of this information (including indirect, special or consequential damages).