

Two red lines intersect on a blue background. One line starts from the top right and goes down-left, ending in a red dot. The other line starts from the top left and goes down-right, ending in a red dot. The intersection point is also marked with a red dot.

ETAS XETK-S4.2

Emulator Probe for Infineon AUDO MAX MCU Family

User Guide

Copyright

The data in this document may not be altered or amended without special notification from ETAS GmbH. ETAS GmbH undertakes no further obligation in relation to this document. The software described in it can only be used if the customer is in possession of a general license agreement or single license. Using and copying is only allowed in concurrence with the specifications stipulated in the contract.

Under no circumstances may any part of this document be copied, reproduced, transmitted, stored in a retrieval system or translated into another language without the express written permission of ETAS GmbH.

© **Copyright 2021** ETAS GmbH, Stuttgart

The names and designations used in this document are trademarks or brands belonging to the respective owners.

XETK-S4.2 - User Guide R10 EN - 07.2021

Contents

1	About this Document	6
1.1	Classification of Safety Messages	6
1.2	Presentation of Instructions	6
1.3	Typographical Conventions	7
1.4	Presentation of Supporting Information	7
2	Basic Safety Notices	8
2.1	General Safety Information	8
2.2	Requirements for Users and Duties for Operators	8
2.3	Intended Use	8
2.4	Identifications on the Product	11
2.5	Taking the Product Back and Recycling	12
2.6	CE Conformity	12
2.7	UKCA Conformity	12
2.8	RoHS Conformity	13
2.9	Declarable Substances	13
2.10	Use of Open Source Software	13
3	Introduction	14
3.1	Applications	14
3.2	Features	15
4	Hardware Description	16
4.1	Architecture	16
4.2	ECU Interface	17
4.3	XETK Ethernet Interface	18
4.4	Power Supply	19
4.5	ECU Voltage Supervisor	19
4.6	Status LEDs	20
4.7	Data Emulation and Data Measurement	21
4.8	JTAG Interface	22
4.9	Trigger Modes: Overview	23
4.10	Pinless Triggering	23
	4.10.1 Startup Handshake	23
	4.10.2 XETK Trigger Generation	23
4.11	Timer Triggering	24
4.12	Reset	24
5	Installation	25
5.1	Connection to the ECU	25

5.2	Wiring	26
5.2.1	XETK Ethernet Interface	26
5.2.2	Power Supply	27
6	XETK Configuration	28
6.1	Overview	28
6.2	Configuration Parameter	29
7	Technical Data	30
7.1	System Requirements	30
7.1.1	ETAS Compatible Hardware	30
7.1.2	PC with one Ethernet interface	30
7.1.3	Software Support	31
7.2	Microcontroller Memory and Microcontroller Support	31
7.2.1	Data Emulation Memory and Microcontroller Support	31
7.2.2	Measurement Data Memory	31
7.3	Configuration	32
7.4	XETK Ethernet Interface	32
7.5	Environmental Conditions	32
7.6	Power Supply	33
7.7	Test Characteristics	34
7.8	JTAG Timing Characteristics	34
7.8.1	JTAG Timing Parameter	35
7.9	Electrical Characteristics	36
7.9.1	ECU Interface Characteristics	36
7.9.2	ECU Interface Connector CON6	39
7.9.3	Interface and Power Supply Connector CON7	39
7.10	Pin Assignment	40
7.10.1	ECU Interface Connector CON6	40
7.10.2	Interface and Power Supply Connector CON7	40
7.11	Mechanical Dimensions	41
8	Cables and Accessories	42
8.1	ECU Adapter Cable	42
8.1.1	CBAM230.1 Adapter Cable	42
8.1.2	CBAM240.1 Adapter Cable	42
8.2	PC Interface Cable	43
8.2.1	CBE200-3 Cable	43
8.2.2	CBAE200.2 Adapter Cable	43
8.3	ETAS Module Interface Adapter Cable	43
8.3.1	CBE230.1 Cable	43
8.3.2	CBAE330.2 Adapter Cable	43
8.4	Power Supply Cables	44
8.4.1	Cable K70	44
8.4.2	Cable KA50	44
8.5	ECU Interface Adapters	45
8.5.1	XETK - ECU Adapter ETA14	45
8.5.2	XETK - ECU Adapter ETA18	45

9	Ordering Information	46
9.1	XETK-S4.2	46
9.2	XETK - ECU Adapter	46
9.3	Power Supply	46
9.4	Cables	46
9.4.1	ECU Adapter Cables	47
9.4.2	Ethernet Cables	47
9.4.3	Power Supply Cables.....	47
10	Contact Information	48
	Figures	49
	Index	50

1 About this Document

1.1 Classification of Safety Messages

The safety messages used here warn of dangers that can lead to personal injury or damage to property:



DANGER

indicates a hazardous situation with a high risk of death or serious injury if not avoided.



WARNING

indicates a hazardous situation of medium risk, which could result in death or serious injury if not avoided.



CAUTION

indicates a hazardous situation of low risk, which may result in minor or moderate injury if not avoided.

NOTICE

indicates a situation, which may result in damage to property if not avoided.

1.2 Presentation of Instructions

The target to be achieved is defined in the heading. The necessary steps for his are in a step-by-step guide:

Target definition

1. Step 1
2. Step 2
3. Step 3
- > Result

1.3 Typographical Conventions

Hardware

Bold	Menu commands, buttons, labels of the product
<i>Italic</i>	Emphasis on content and newly introduced terms

1.4 Presentation of Supporting Information



NOTE

Contains additional supporting information.

2 Basic Safety Notices

This chapter contains information about the following topics:

- General Safety Information 8
- Requirements for Users and Duties for Operators 8
- Intended Use 8
- Identifications on the Product. 11
- Taking the Product Back and Recycling 12
- CE Conformity 12
- UKCA Conformity 12
- RoHS Conformity 13
- Declarable Substances. 13
- Use of Open Source Software. 13

2.1 General Safety Information

Please observe the Product Safety Notices ("ETAS Safety Notice") and the following safety notices to avoid health issues or damage to the device.



NOTE

Carefully read the documentation (Product Safety Advice and this User Guide) that belongs to the product prior to the startup.

ETAS GmbH does not assume any liability for damages resulting from improper handling, unintended use or non-observance of the safety precautions.

2.2 Requirements for Users and Duties for Operators

The product may be assembled, operated and maintained only if you have the necessary qualification and experience for this product. Incorrect operation or operation by users without sufficient qualification may lead to injuries or death or property damages.

General Safety at Work

The existing regulations for safety at work and accident prevention must be followed. All applicable regulations and statutes regarding operation must be strictly followed when using this product.

2.3 Intended Use

An ETK is an electronic component that is installed in a vehicle control unit (ECU) to read data from the ECU or write data to the ECU.

Application Area of the Product

This product was developed and approved for automotive applications. For use in other application areas, please contact your ETAS contact partner.

Requirements for Operation

The following requirements are necessary for safe operation of the product:

- Use the product only according to the specifications in the corresponding User Guide. With any deviating operation, the product safety is no longer ensured.
- Observe the regulations applicable at the operating location concerning electrical safety as well as the laws and regulations concerning work safety!
- Do not apply any voltages to the connections of the product that do not correspond to the specifications of the respective connection.
- Connect only current circuits with safety extra-low voltage in accordance with EN 61140 (degree of protection III) to the connections of the product.
- The power supply for the product must be safely disconnected from the supply voltage. For example, use a car battery or a suitable lab power supply.
- Use only lab power supplies with double protection to the supply system.
- Ensure that the connections of the power supply are easily accessible.
- The module does not have an operating voltage switch.
 - Switch on the product by connecting the power supply cable with the power supply or by switching on the power supply.
 - Switch off the product by disconnecting it from the power supply or by switching off the power supply.



DANGER

Connect the power cord only with a vehicle battery or with a lab power supply! A connection to power outlets is prohibited.

Route the power cord in such a way that it is protected against abrasion, damages, deformation and kinking. Do not place any objects on the power cord.

Never apply force to insert a plug into a socket. Ensure that there is no contamination in and on the connection, that the plug fits the socket, and that you correctly aligned the plugs with the connection.

Do not use the product in a wet or damp environment.

Do not use the product in potentially explosive atmospheres.

Keep the surfaces of the product clean and dry.

Potential Equalization



CAUTION

Danger from inadvertent current flow!

Depending on the design, the shield of the Ethernet cables can be connected with the housing of the module. Install the products only on components with the same electrical potential or isolate the products from the components.

Requirements for the technical State of the Product

The product is designed in accordance with state-of-the-art technology and recognized safety rules. The product may be operated only in a technically flawless condition and according to the intended purpose and with regard to safety and dangers as stated in the respective product documentation. If the product is not used according to its intended purpose, the protection of the product may be impaired.

Maintenance and Cleaning

The product is maintenance-free. Use a lightly moistened, soft, lint-free cloth for cleaning the product. Ensure that no moisture can enter. Never spray cleaning agents directly onto the product. Do not use any sprays, solvents or abrasive cleaners which could damage the product.

Transport and Installation



CAUTION

The ETK can be damaged or destroyed!

Some components of the ETK board may be damaged or destroyed by electrostatic discharges. Please keep the ETK in its storage package until it is installed.

The board should only be taken from its package, configured, and installed at a work place that is protected against static discharge.



CAUTION


During installation and removal, ECU and ETK must be in a de-energized state!



CAUTION

Risk of short circuiting the internal signals of the ETK!

When you mount the ETK to the ECU, you must ensure that the screws and washers used will not penetrate the ETK printed circuit board.



CAUTION

Differences in case ground potentials can cause high currents to flow through the shields of the cables that connect various system modules.

Ensure that the module mounting surfaces are at the same electrical potential or insulate the modules from their mounting surfaces.

Cabling








Use exclusively ETAS cables at the connections of the product! Adhere to the maximum permissible cable lengths! Observe the assignment of the cables to the connectors! Detailed information about cabling is located in the ETK User Guides.

2.4 Identifications on the Product



Fig. 2-1 Adhesive Label (Example: Label for XETK-S14.0)

The following symbols are used for identifications of the product:

Symbol	Description
	The User Guide must be read prior to the startup of the product!
	Symbol for WEEE, see chapter 2.5 on page 12
	Marking for CE conformity (Chapter 2.6 on page 12)
	Marking for UKCA conformity (Chapter 2.7 on page 12)
	Symbol for China RoHS, see chapter on page 13
	Symbol for China RoHS, see chapter on page 13
	Symbol for electrostatic sensitive components
XETK-S14.0A	Product designation (example)
F 00K 110 722	Order number of the product (example)
SN: yyxxxxx	Serial number (7-digit)

Symbol	Description
XXXX/YY	Product version
ZZZZ	Year of manufacture
ETAS GmbH, PO Box 300220, 70442 Stuttgart, Germany	Manufacturer's address



NOTE

For symbols and product information one or several adhesive labels can be used.

2.5 Taking the Product Back and Recycling

The European Union has passed a directive called Waste Electrical and Electronic Equipment, or WEEE for short, to ensure that systems are setup throughout the EU for the collection, treating and recycling of electronic waste.

This ensures that the devices are recycled in a resource-saving way representing no danger to health or the environment.



Fig. 2-2 WEEE-Symbol

The WEEE symbol (see Fig. 2-2 on page 12) on the product or its packaging shows that the product must not be disposed of as residual garbage.

The user is obliged to collect the old devices separately and return them to the WEEE take-back system for recycling. The WEEE directive concerns all ETAS devices but not external cables or batteries.

For more information on the ETAS GmbH Recycling software, contact the ETAS sales and service locations.

2.6 CE Conformity

With the CE mark attached to the product or its packaging, ETAS confirms that the product corresponds to the product-specific, applicable directives of the European Union.

The CE Declaration of Conformity for the product is available upon request.

2.7 UKCA Conformity

With the UKCA mark attached to the product or its packaging, ETAS confirms that the product corresponds to the product-specific, applicable standards and directives of Great Britain.

The UKCA declaration of conformity for the product is available on request.

2.8 **RoHS Conformity**

European Union

The EU Directive 2011/65/EU limits the use of certain dangerous materials for electrical and electronic devices (RoHS conformity).

This product does not contain any of the restricted substances specified in the EU Directive 2011/65/EU or exceeds the maximum concentrations stipulated therein. For individual electronic components used in our products, there are currently no equivalent alternative substances, which is why we make use of the exceptions 7A and 7C-I in Annex III of this Directive.

ETAS confirms that the product corresponds to this directive which is applicable in the European Union.

China

ETAS confirms that the product meets the product-specific applicable guidelines of the China RoHS (Management Methods for Controlling Pollution Caused by Electronic Information Products Regulation) applicable in China with the China RoHS marking affixed to the product or its packaging.

2.9 **Declarable Substances**

European Union

Some products from ETAS GmbH (e.g. modules, boards, cables) use components with substances that are subject to declaration in accordance with the REACH regulation (EU) no.1907/2006.

Detailed information is located in the ETAS download center in the customer information "REACH Declaration" (www.etas.com/Reach). This information is continuously being updated.

2.10 **Use of Open Source Software**

The product uses Open Source Software (OSS). This software is installed in the product at the time of delivery and does not have to be installed or updated by the user. Reference shall be made to the use of the software in order to fulfill OSS licensing terms. Additional information is available in the document "OSS Attributions List" at the ETAS website www.etas.com.


3 Introduction

This chapter contains information about the following topics:

- Applications 14
- Features 15

3.1 Applications

The XETK-S4.2 is an emulator probe for the Infineon AUDDO-MAX microcontroller (Infineon TriCore TC17xx).

 **NOTE**
 For supported TC17xx microcontrollers, refer to chapter 7.1.3 on page 31.

It is a typical serial XETK with an Infineon specific JTAG interface.




Fig. 3-1 XETK-S4.2

	XETK-S4.2
ECU connectors	12 pin ERNI plus 7 pin JST
Power supply for ED devices (VDDS-BRAM)	min. 1.5 V or min. 1.3 V
SBRAM sense	Yes, no extra pin
Pinless triggering	Yes
Timer triggering	Yes

The XETK-S4.2 supports the standard full duplex 100Base-T Ethernet interface and can be connected directly or via ES51x/ES59x/ES600 modules to the PC. No additional ETAS modules are required for the access to the ECU. The XETK-S4.2 can be used for rapid prototyping applications (bypass) as well as for measurement and calibration applications.

3.2 Features

- Measurement Interface:
 - For use with serial processor interface JTAG (Infineon)
 - JTAG interface clock speed: 40 MHz
 - 3.3 V ECU interface voltage level
 - Supports coldstart measurement mechanism
- Pinless startup protocol for XETK recognition
- Microcontroller capability of internal Flash emulation can be used
- Permanent storage of configuration in EEPROM
- XETK powers Emulation Device RAM (for calibration purpose)
- Fast Ethernet Interface:
 - Direct Connection to PC
 - Open XCP on Ethernet Protocol
 - Supports a variety of standard applications
- Firmware update (programming of the logic device) through software; removal of XETK or ECU is not necessary
- Mounting possibilities inside or on top of ECU
- Temperature range suitable for automotive application

For more technical data on the XETK-S4.2 consult the chapter “Technical Data” on page 30.

4 Hardware Description

This chapter contains information about the following topics:

- Architecture 16
- ECU Interface 17
- XETK Ethernet Interface 18
- Power Supply 19
- ECU Voltage Supervisor 19
- Status LEDs 20
- Data Emulation and Data Measurement 21
- JTAG Interface 22
- Trigger Modes: Overview 23
- Pinless Triggering 23
- Timer Triggering 24
- Reset 24

4.1 Architecture

Fig. 4-1 shows the block diagram of the XETK-S4.2.




Fig. 4-1 XETK-S4.2 Architecture

While the microcontroller accesses the program data (not the program code) out of the data emulation memory provided by the microcontroller (TC17xx), the content of the data emulation memory can simultaneously be modified by the calibration and development system through the XETK Ethernet interface. This process enables adjustments of parameters, characteristic lines and maps through the calibration and development system. Using an additional

measurement data memory area, the ECU microcontroller can provide data to the calibration and development system by buffering the data (DISTAB13) and triggering the XETK to read the data via JTAG. The XETK then reads, buffers, processes and sends this measured data to the PC.

If no additional measurement data memory is available, the XETK-S4.2 can alternatively read the data to be measured directly from the microcontroller's memory. This process is Triggered Direct Measurement (TDM) with DISTAB13. The 100 Mbit/s XETK Ethernet interface provides communication with the PC. The power supply for the XETK-S4.2 is provided by a switch mode power supply, to minimize power dissipation.

4.2 ECU Interface

The XETK-S4.2 is connected via connectors CON6 and CON7 to the ECU with two adapter cables (refer to Fig. 4-2 on page 17). The pin definition depends on the application and the microcontroller type. In general the ECU interface consists of

- 1 ECU voltage line, which is not used for XETK power supply, but only for detection of the ECU status, therefore the power consumption on this line is negligible (refer to chapter 4.4 on page 19)
- 1 Reset line which allows the XETK to control the system reset of the ECU
- 1 Reset line which allows the XETK to monitor the system reset of the ECU
- 7 Debug Interface lines for the communication between the XETK-S4.2 and the microcontroller
- 2 ground lines for proper shielding of the ECU interface lines




Fig. 4-2 Location of the ECU Interfaces

4.3 XETK Ethernet Interface

The XETK Ethernet interface shown in Fig. 4-3 can be directly connected to the PC. No additional ETAS module is required for the access to the ECU.

The interface is a standard full duplex 100Base-TX Ethernet interface using the XCP protocol. The XETK Ethernet interface is integrated in the ETAS IP world with automatic IP management and supports the open automotive "Universal Measurement and Calibration" standard "XCP on Ethernet" (TCP/IP, UDP/IP). The open XCP on Ethernet interface allows for connecting to the XETK-S4.2 with third party application software.

NOTE

The XETK Ethernet interface is not compatible with the ETK interfaces in modules like e.g. ES910, ES590, ES591, ES592, ES593-D, ES595, ES1232-A. The XETK Ethernet interface is compatible with the ECU interface of the ES910 module and the Ethernet interfaces of the ES51x/ ES592/ ES593-D/ ES595/ ES600 / ES88x / ES89x modules.

NOTE

Please see chapter 7.1.2 on page 30 for additional information regarding PC requirements for the Ethernet interface.




Fig. 4-3 Location of the XETK Ethernet Interface connector (CON5)

4.4 Power Supply

The XETK-S4.2 requires a permanent power supply. It is typically powered directly from the car battery. The input voltage may vary between 4.3 V and 36 V. In case of higher input voltages to the XETK, additional voltage protection is required. The XETK-S4.2 will also accept voltage dips down to 3V, for a maximum duration of 15ms (for additional details of low voltage operation, see ISO standard 16750).

From the input battery voltage, the XETK-S4.2 creates all necessary voltages through switching power supplies on the XETK-S4.2. The power supply of the ECU is not affected by the XETK-S4.2. An automatic switch ensures that the power supply of the XETK-S4.2 is automatically switched on and off when the XETK enters and leaves its standby (sleep) mode.

The XETK-S4.2 can be supplied with power through the seven pin connector, CON7. The through-hole solder pad CON4 can be used additionally to connect a power supply U_{Batt2} .

The power supply on CON4 must use the GND of CON7 pin 3.




Fig. 4-4 Location of the XETK-S4.2 Power Supply Connectors

4.5 ECU Voltage Supervisor

The ECU voltage (VDDP) is monitored by the XETK to recognize whether the ECU is switched on or off.

Additionally the ECU RAM standby voltage (VDDSB RAM) is monitored to determine if the standby RAM content is still valid. These two signals are only used for monitoring therefore the load current is negligible.

The XETK-S4.2 supplies the ECU EDRAM using the pin VDDSB RAM and monitors this voltage using a sense pin on board the XETK. The microcontroller's standby power supply pin must be connected to the XETK pin VDDSB RAM.

NOTE

The XETK-S4.2 only allows switching between reference page and working page if there is a valid voltage at the sense pin and the working page has been initialized by the calibration and development system.

4.6 Status LEDs

There are three LEDs displaying the operating status of the XETK-S4.2 (Fig. 4-5 on page 20).




Fig. 4-5 Status LEDs of the XETK-S4.2

LED	State	Definition
Red	On	XETK-S4.2 is supplied with power and active (i.e. the ECU is switched on or the 100 Mbit/s link to the calibration system is established)
Green	Off	Working page may be different from reference page. Calibration and development system has downloaded data since the last power failure. Switching between the Reference Page and Working Page is possible.
	On	Power supply has dropped under selected threshold: - data retention of the calibration data manager in the ECU is no longer ensured - as soon as the XETK-S4.2 switches on again, the ECU switches to the Reference Page. Green LED stays on until the calibration and development system downloads data into the calibration data memory. Otherwise switching to the Working Page is not possible.
Yellow	Flashing	Communication active
	On	100 Mbit/s link to calibration system established

4.7 Data Emulation and Data Measurement

The XETK-S4.2 is a serial XETK using JTAG as the primary microcontroller interface. Typical of all serial (X)ETKs, the RAM used for data emulation and data measurement is not accessible by the XETK until the microcontroller is powered up and the startup handshake is performed.

Serial XETKs use the ETAS two page concept, consisting of both a Reference and a Working page.

The Reference Page is located in the ECU flash and can not be modified by a simple write access. All changes to the Reference Page must be done via Flash programming.

The Working Page is located within the microcontroller's ED RAM. The Working Page may be a portion of or the entire size of the ED RAM. The ED RAM used for the emulation of calibration data must not be used by the ECU software directly as general purpose RAM. It is recommended that the ED RAM is permanently powered by the XETK. The XETK/INCA has the complete control over the RAM used as Working Page and its contents. When enabling data emulation, the XETK establishes a basic start-up configuration of the data in the Working Page by copying the corresponding data in the Flash to the emulation space.

To enable calibration, the Working Page must be activated. The process of switching from the Reference Page to the Working Page and vice versa is known as page switching.

The XETK-S4.2 supports Protocol Based page switching for all supported microcontrollers. Switching between Reference and Working Page is done in microcontroller software by switching the overlay memory on (Working Page) and off (Reference Page) using microcontroller overlay registers. The XETK-S4.2 does not directly control the microcontroller overlay registers. Instead the XETK-S4.2 and microcontroller software use a simple communication method with a shared mailbox in RAM. The XETK uses this mailbox to request and monitor page switching; the microcontroller software is responsible to service this mailbox and perform the page switches. Using an overlay configuration table, also in RAM, the XETK provides the necessary information of how the overlay registers need to be modified to realize the page switch which is requested.

The XETK-S4.2 can only access the Reference Page when the microcontroller software is running on the Reference Page. When the Working Page is active, there is no access to the Reference Page by the XETK or the microcontroller. If the ECU is running from the Working Page, a page switch must be done to perform actions like upload or checksum calculation on the Reference Page.

Another important restriction is that no access to the memory is possible, while the ECU is not running. To enable a cold start measurement in spite of this restriction, a special procedure is defined to give the user the feeling of a parallel XETK.

4.8 JTAG Interface




Fig. 4-6 Equivalent Circuitry of the ECU JTAG Interface (ECU)

The ECU part of the JTAG XETK interface is depicted in Fig. 4-6. For proper operation it is mandatory for the ECU to provide series termination resistors of 22 Ohm in series with the /BRKOUT and TDO lines on the ECU PCB.

The XETK-S4.2 incorporates 22 Ohm series resistors for the TMS, TCK, TDI and /TRST lines on the ECU interface. Hence, no additional termination resistors are required on the ECU / debugger PCB for these signals.

It is mandatory for the ECU to provide impedance matched series termination resistors of 22 Ohms for the signals TDO and /BRKOUT as shown in Fig 3-6. Additionally, if a pulldown resistor is present on the line /TRST, the ECU must use a value no smaller than 100K ohm as shown in Fig. 4-6 on page 22.

The signals /BRKIN and /BRKOUT pass through the XETK directly to the debugger, with no connection to the XETK-S4.2 logic.

4.9 Trigger Modes: Overview

The XETK-S4.2 supports the following trigger modes:

- Pinless triggering
- Timer triggering

The trigger mode "Pinless Triggering" uses an internal JTAG register for triggering. See also chapter "Pinless Triggering" on page 23.

The trigger mode "Timer Triggering" uses four internal timers of the XETK for triggering. See also chapter "Timer Triggering" on page 24.

4.10 Pinless Triggering

NOTE

The XETK-S4.2 uses the pinless startup and triggering feature with the microcontroller Infineon AU00 MAX microcontroller family.

4.10.1 Startup Handshake

The registers CBS_TRIG and CBS_OSTATE.OJC are initialized to 0x0 during reset.

When the reset is deactivated (as detected by the /HDRST signal) a special pattern is written to the OJC[3..1] bits of the CBS_OSTATE register of the CPU by the XETK via the IO_SET_OJCONF JTAG command. This pattern includes the power fail status of the standby supply. (No power fail: write "001", Power fail: write "011").

The ECU software must wait at least 50 μ s from reset before reading the CBS_OSTATE register to ensure the XETK-S4.2 has completed the IO_SET_OJCONF operation.

Application running

The ECU software detects the connected XETK by reading CBS_OSTATE register. Thereafter the ECU software performs basic initializations and when finished writes 00005555h to CBS_TRIGS register. The XETK is periodically polling CBS_TRIG and detects the xxxx5555h pattern. The startup handshake is finished, the XETK then starts initialization and data acquisition (e.g. cold-start, checksum, downloads, etc).

4.10.2 XETK Trigger Generation

Initialization

After the startup handshake and measurement is enabled, the XETK is waiting for triggers from the ECU software.

Application running

To generate triggers, the ECU software sets bits in the trigger register "CBS_TRIG" by writing the associated bits in the trigger setting register "CBS_TRIGS".

Each bit of the trigger setting register "CBS_TRIGS" corresponds to a bit in the same position in the trigger register "CBS_TRIG", each of them corresponding to an XETK hardware trigger.

The XETK periodically polls the trigger register "CBS_TRIG" via IO_READ_TRIG for detecting triggers. The polling rate is determined by the fastest measurement raster and is configurable with a 50 μ s default.

Active bits in trigger register "CBS_TRIG" are automatically cleared by the CPU when the register is read by the XETK-S4.2 via IO_READ_TRIG. For generating triggers, the ECU software sets bits in the trigger register "CBS_TRIG" by writing the associated bits in the trigger setting register "CBS_TRIGS".

4.11 Timer Triggering

The trigger mode "Timer Triggering" uses four internal timers of the XETK-S4.2 for triggering. A fixed configurable period is used for triggering.

The time intervals between trigger events are in accordance with the configured timer values. These values and their resolution have to be defined in the A2L file. Available settings are:

- Minimum time interval 100 μ s
- Maximum period duration 1 s
- Timer resolution 1 μ s

The timers work in an asynchronous manner to the ECU.

4.12 Reset

The requirement for the XETK-S4.2 reset mechanism is to ensure that power-up and power-down behavior of ECU is clean and smooth. The XETK-S4.2 normally drives /PORST low during XETK power up or upon INCA request.


The signal /HDRST of the microcontroller is used by the XETK-S4.2 to detect when the ECU is in reset.

The XETK-S4.2 senses the switched ECU power supply. This allows it to detect when the ECU is off and forward this information to INCA. In addition, it allows the XETK to enter the power save mode with the calibration system unplugged.

5 Installation

This chapter contains information about the following topics:


- Connection to the ECU 25
- Wiring 26

 **CAUTION**

Some components of the interface board may be damaged or destroyed by electrostatic discharges. Please keep the board in its storage package until it is installed.

The board should only be taken from its package, configured, and installed at a work place that is protected against static discharge.

5.1 Connection to the ECU

 **CAUTION**

Risk of short circuiting the internal signals of the XETK!

When you mount the XETK to the ECU, you must ensure that the screws and washers used will not penetrate the XETK printed circuit board.

For connecting the XETK-S4.2 to the ECU two XETK adapter cables are recommended:

- at CON6 adapter ETAI4
- at CON7 adapter ETAI8

The adapter cables are to be ordered separately (refer chapter “Ordering Information” on page 46).

The suitable connectors JST-7 and ERNI-12 (see Fig. 5-2 for additional connector details) should have been populated onto the ECU PCB for adapters ETAI4 and ETAI8.




Fig. 5-1 XETK-S4.2 Connection to the ECU




Fig. 5-2 XETK-S4.2C Connection to the ECU and to the Debugger

5.2 Wiring

5.2.1 XETK Ethernet Interface




Fig. 5-3 Wiring - XETK Ethernet Interface

The XETK Ethernet interface can be directly connected to the PC. No additional ETAS module is required for the access to the ECU.

NOTE

The XETK Ethernet interface is compatible with the Ethernet interfaces of the ES51x/ES59x/ES600/ES910 / ES88x / ES89x module.

5.2.2 Power Supply

The XETK-S4.2 needs a permanent power supply (refer chapter "Power Supply" on page 19). There are different versions to ensure it.

Permanent Power Supply inside ECU available




Fig. 5-4 Permanent Power Supply inside ECU available

Permanent Power Supply inside ECU not available




Fig. 5-5 Permanent Power Supply inside ECU not available

Isolated Power Supply inside ECU

The XETK-S4.2 does not require a galvanically isolated power supply. For special applications ETAS offers the isolated power supply ETP2.




Fig. 5-6 Isolated Power Supply inside ECU

6 XETK Configuration

This chapter contains information about the following topics:

- Overview 28
- Configuration Parameter 29

6.1 Overview

As already mentioned in previous chapters, some project-specific adjustments are necessary. Configuration data is stored permanently in a serial Flash.

Generating a valid configuration data set is supported by the "(X)ETK Configuration Tool" (XCT). The "(X)ETK Configuration Tool" contains information on all available XETKs and ETKs like ETK-S20, ETK-S21 and ETK-S22. The user is supported through a graphical interface.

The configuration is done in two steps:

1. Generation of the special address offset for the emulation and measurement data memory.

The location of data areas, measured data output areas, trigger segment addresses etc. are familiar to the ECU software developer, or can be generated automatically. If an ECU description database (ASAP, ...) with the corresponding input exists, these inputs can be downloaded from this database. If necessary, a plausibility check is performed.

2. Connection of the ETK to the ECU.

The ECU hardware developer defines the connection of the ETK to the ECU. The corresponding signals usually have to be adjusted for each microcontroller. All inputs are checked for plausibility, to make sure that a valid configuration is generated.

The "(X)ETK Configuration Tool" can create the following output:

- Direct ETK configuration
- Storage of the configuration in a data file
- The corresponding ASAP2 input

The most important outputs are the entries for the ASAP2 file. All A2L definitions necessary for configuring an ETK will be created. These are:

- Overlay Region definitions
- Memory Segment definitions
- ETK configuration features
- Raster definitions

If this parameters are entered correctly in the corresponding ECU description file, it guarantees that every time the calibration system is started, the ETK is checked for the appropriate configuration. If necessary, the ETK will be configured appropriately to the corresponding project.

6.2 Configuration Parameter

The "(X)ETK Configuration Tool" provides support concerning hardware configuration parameters and their possible values.

They are described for the different ETK types in the help document of the "(X)ETK Configuration Tool".

Starting the "(X)ETK Configuration Tool" help

1. Start the "(X)ETK Configuration Tool".
The main window of the XCT tool opens.
2. Select in the menu bar ? > Contents.
The "(X)ETK Configuration Tool" help window opens.
3. Choose Reference to User Interface > (X)ETK Hardware Configuration Parameters.
4. Choose the topic XETK-S4.2.
The topic XETK-S4.2 contains information about the XETK-S4.2 hardware configuration parameters and their possible values.

7 Technical Data

This chapter contains information about the following topics:

- System Requirements 30
- Microcontroller Memory and Microcontroller Support 31
- Configuration 32
- XETK Ethernet Interface 32
- Environmental Conditions 32
- Power Supply 33
- Test Characteristics 34
- JTAG Timing Characteristics 34
- Electrical Characteristics 36
- Pin Assignment 40
- Mechanical Dimensions 41

7.1 System Requirements

7.1.1 ETAS Compatible Hardware

Compact Hardware: ES51x, ES592, ES593-D, ES595, ES600, ES910

ETAS Hardware: ES88x and ES89x ECU Interface Modules

7.1.2 PC with one Ethernet interface

A PC with one open Ethernet interface (1 Gbit/s or 100 Mbit/s, full duplex) with RJ-45 connection is required. Ethernet interfaces that are implemented with an additional network card in the PC must feature a 32-bit data bus.

 **NOTE**

Half Duplex mode and Half Duplex Ethernet interfaces are not supported.

Requirement to ensure successful Initialization of the Module

 **NOTE**

It is imperative you disable the function which automatically switches to power-saving mode on your PC network adapter when there is no data traffic on the Ethernet interface!

To deactivate the Power saving Mode

Choose in System Control Center / Device Manager / Network Adapter the used network adapter by double-click. Deactivate the "Allow the computer to turn off this device to save power" option in the "Power Management" register. Confirm your configuration.

The manufacturers of network adapter have different names for this function.

Example:

- "Link down Power saving"
- "Allow the computer to turn off this device to save power"

7.1.3 Software Support

You need following software versions to support the XETK-S4.2:

Micro-controller	HSP	INCA	ETK Drivers and Tools
TC1728ED	V10.2.0	V7.0.0 HF18; V7.1.2	3.11.0
TC1782ED	V10.2.0	V7.0.0 HF18; V7.1.2	3.11.0
TC1793ED	V10.0.0	V7.0.0 HF18	3.9.0
TC1797ED	V10.2.0	V7.0.0 HF18; V7.1.2	3.11.0
TC1798ED	V10.0.0	V7.0.0 HF18	3.9.0
TC1798	V10.0.0	V7.0.0 HF18	3.9.0

Operating the XETK-S4.2 with older software versions is not possible.

The configuration instructions for the XETK-S4.2 under INCA and HSP are contained in the relevant software documentation.

7.2 Microcontroller Memory and Microcontroller Support

7.2.1 Data Emulation Memory and Microcontroller Support

The XETK-S4.2 uses a portion of or up to the entire size of the ED RAM, to emulate data in internal flash. The following table lists the supported microcontrollers, the size of the ED RAM, and states if the ED RAM is capable of being powered using a standby supply.

Microcontroller	Max. ED RAM	Standby powered
TC1728ED	384 kByte	Yes
TC1782ED	512 kByte	Yes
TC1793ED	768 kByte	Yes
TC1797ED	512 kByte	Yes
TC1798ED	768 kByte	Yes
TC1798	n.a.	n.a.

7.2.2 Measurement Data Memory

Item	Characteristics
Location	Typically located within the emulation memory when using DISTAB13 hooks. Measurement data memory can be located in internal RAM if EMEM is needed for calibration.

7.3 Configuration

Item	Characteristics
Configuration	Project-specific configuration for - different microcontrollers or - memory configurations stored in EEPROM
Update	Logic devices updated using HSP software

7.4 XETK Ethernet Interface

Item	Characteristics
Connection	- 100 MBit/s Ethernet, Full Duplex - PC Card 32 bit
Protocol	XCP on TCP/IP or UDP/IP
IP address	Dynamic (standard, for INCA) or static (e.g. for Rapid Prototyping) by using the XETK Configuration Tool (default IP address: 192.168.40.16)
Cable length	max. 30 m / 100 ft
Ethernet Interface	DC decoupling



NOTE

To ensure successful initialization of the network card of your PC, refer to chapter 7.1.2 on page 30

7.5 Environmental Conditions

Item	Characteristics
Temperature range (operation)	- 40 °C to +110 °C/ - 40 °F to +230 °F
Temperature range (storage)	0 °C to +50 °C/ - 18 °F to +122 °F
Relative humidity (non-condensing)	0 to 95%
Operating altitude	max. 5000 m/ 16400 ft
Contamination level	2
Degree of protection	Determined by installation in ECU
Overvoltage category (AC mains supply)	II

7.6 Power Supply

Parameter	Symbol	Condition	Min	Typ	Max	Unit
Permanent power supply (car battery)	U_{Batt}	Vehicle usage ¹⁾	4.3	12	36	V
[all values $\pm 0\%$]						
Standby current ²⁾	I_{STBY}	$U_{\text{Batt}} = 12 \text{ V}$; ECU off; no load from ECU; $T = 20 \text{ }^\circ\text{C}$		35	40	mA
Operating current	I_{Batt}	$U_{\text{Batt}} = 12 \text{ V}$; $I = 0 \text{ mA}$ at pin ECU_SBRAM; $T = 20 \text{ }^\circ\text{C}$		135	200	mA
Operating current	I_{Batt}	$U_{\text{Batt}} = 12 \text{ V}$; $I = 600 \text{ mA}$ at pin ECU_SBRAM; $T = 20 \text{ }^\circ\text{C}$		240	300	mA
Power dissipation	P_{Batt}	$U_{\text{Batt}} = 12 \text{ V}$; $I = 0 \text{ mA}$ at pin ECU_SBRAM; $T = 20 \text{ }^\circ\text{C}$		1.62		W
Power dissipation	P_{Batt}	$U_{\text{Batt}} = 12 \text{ V}$; $I = 600 \text{ mA}$ at pin ECU_SBRAM; $T = 20 \text{ }^\circ\text{C}$		2.88		W

1) The XETK-S4.2 implements reverse voltage protection in the same range and may be used only with central load dump protection.
24 V vehicles require U_{Batt} disturbing pulse reduction to 12 V vehicle system.
12 V vehicles don't require special disturbing pulse reductions.

2) if $I = 0 \text{ mA}$ at pin VDDSRAM_OUT

NOTE

The XETK-S4.2 will accept permanent power supply voltage dips (for additional details of 3 V low voltage operation, see ISO standard 16750).

7.7 Test Characteristics

Parameter	Symbol	Condition	Min	Typ	Max	Unit
Reset delay 1 ¹⁾	t_{Reset1}	$U_{\text{Batt}} = 12 \text{ V}$ $V_{\text{DDP}} = 0 \text{ V} \uparrow 3.3 \text{ V}/$ 5.0 V without transferring FPGA	29		40	ms
Reset delay 2 ²⁾	t_{Reset2}	$U_{\text{Batt}} = 0 \text{ V} \uparrow 12 \text{ V}$ transfer FPGA	100		240	ms

¹⁾ Delay of ECU reset through the XETK without transferring the FPGA (U_{Batt} present, V_{DDP} will be switched on)

²⁾ max. delay of ECU reset through the XETK (U_{Batt} and V_{DDP} will be switched on)

7.8 JTAG Timing Characteristics

The following diagrams show the timings the XETK-S4.2 can process.



NOTE

JTAG timing parameters in this chapter refer to the JTAG interface (CON1/ CON6) of the XETK-S4.2. The JTAG wiring to the ECU (ETA1/ ETA11) must be taken account additionally.

All timings are measured at a reference level of 1.5 V. Output signals are measured with 20 pF to ground and 50 Ω to 1.5 V.

7.8.1 JTAG Timing Parameter

JTAG 40 MHz Clock			
Parameter	Min	Max	Units
t_{TCK}	25	25	ns
t_{CO_TDI}	-3.5	4.5	ns
t_{CO_TMS}	-3.5	4.5	ns
t_{SU_TDO}	-4	n/a	ns
t_{H_TDO}	3	n/a	ns




Fig. 7-1 XETK-S4.2 JTAG Timing Diagram (40 MHz)

7.9 Electrical Characteristics

7.9.1 ECU Interface Characteristics

Parameter	Symbol	Condition ¹⁾	Min	Typ	Max	Unit
CalWakeup Output Voltage	CALWAKEUP	$U_{\text{Batt}} = 6 - 18 \text{ V};$ load 0 - 50 mA	$U_{\text{Batt}} - 1 \text{ V}$		U_{Batt}	V
ECU Power Supply Supervision Voltage (3.3 V selected)	VDDP	VDDP \uparrow	2.48	2.58	2.68	V
		VDDP \downarrow	2.33	2.43	2.53	V
	I_{VDDP}	VDDP = 3.3 V			200	μA
ECU Power Supply Supervision Voltage (5.0 V selected)	VDDP	VDDP \uparrow	2.98	3.08	3.18	V
		VDDP \downarrow	2.83	2.93	3.03	V
	I_{VDDP}	VDDP = 5.0 V			300	μA
ECU Standby RAM Supervision Voltage ([0.74 V - 0.97 V] selected)	VDDSB RAM	VDDSB RAM \uparrow	0.74	0.84	0.94	V
		VDDSB RAM \downarrow	0.77	0.87	0.97	V
	$I_{\text{VDDSB RAM}}$	VDDSB RAM = 1.0 V			60	μA
ECU Standby RAM Supervision Voltage ([0.81 V - 1.04 V] selected)	VDDSB RAM	VDDSB RAM \uparrow	0.81	0.91	1.01	V
		VDDSB RAM \downarrow	0.84	0.94	1.04	V
	$I_{\text{VDDSB RAM}}$	VDDSB RAM = 1.1 V			65	μA
ECU Standby RAM Supervision Voltage ([0.87 V - 1.10 V] selected)	VDDSB RAM	VDDSB RAM \uparrow	0.87	0.97	1.07	V
		VDDSB RAM \downarrow	0.90	1.00	1.10	V
	$I_{\text{VDDSB RAM}}$	VDDSB RAM = 1.2 V			70	μA
ECU Standby RAM Supervision Voltage ([0.91 V - 1.14 V] selected)	VDDSB RAM	VDDSB RAM \uparrow	0.91	1.01	1.11	V
		VDDSB RAM \downarrow	0.94	1.04	1.14	V
	$I_{\text{VDDSB RAM}}$	VDDSB RAM = 1.3 V			75	μA

Parameter	Symbol	Condition ¹⁾	Min	Typ	Max	Unit
ECU Standby RAM Supervision Voltage ([1.00 V - 1.22 V] selected)	VDDSB RAM	VDDSB RAM ↑	1.00	1.10	1.20	V
		VDDSB RAM ↓	1.02	1.12	1.22	V
	I _{VDDSB RAM}	VDDSB RAM = 1.4 V			85	μA
ECU Standby RAM Supervision Voltage ([1.18 V - 1.41 V] selected)	VDDSB RAM	VDDSB RAM ↑	1.18	1.28	1.38	V
		VDDSB RAM ↓	1.21	1.31	1.41	V
	I _{VDDSB RAM}	VDDSB RAM = 1.5 V			90	μA
ECU Standby RAM Supervision Voltage ([1.29 V - 1.51 V] selected)	VDDSB RAM	VDDSB RAM ↑	1.29	1.39	1.49	V
		VDDSB RAM ↓	1.31	1.41	1.51	V
	I _{VDDSB RAM}	VDDSB RAM = 1.6 V			95	μA
ECU Standby RAM Supervision Voltage ([1.43 V - 1.65 V] selected)	VDDSB RAM	VDDSB RAM ↑	1.43	1.53	1.63	V
		VDDSB RAM ↓	1.45	1.55	1.65	V
	I _{VDDSB RAM}	VDDSB RAM = 1.7 V			100	μA
ECU Standby RAM Supervision Voltage ([1.57 V - 1.79 V] selected)	VDDSB RAM	VDDSB RAM ↑	1.57	1.67	1.77	V
		VDDSB RAM ↓	1.59	1.69	1.79	V
	I _{VDDSB RAM}	VDDSB RAM = 1.9 V			110	μA
ECU Standby RAM Supervision Voltage ([1.72 V - 1.95 V] selected)	VDDSB RAM	VDDSB RAM ↑	1.72	1.82	1.92	V
		VDDSB RAM ↓	1.75	1.85	1.95	V
	I _{VDDSB RAM}	VDDSB RAM = 2.0 V			115	μA
ECU Standby RAM Supervision Voltage ([1.87 V - 2.09 V] selected)	VDDSB RAM	VDDSB RAM ↑	1.87	1.97	2.07	V
		VDDSB RAM ↓	1.89	1.99	2.09	V
	I _{VDDSB RAM}	VDDSB RAM = 2.2 V			130	μA

Parameter	Symbol	Condition ¹⁾	Min	Typ	Max	Unit
ECU Standby RAM Supervision Voltage ([2.02 V - 2.24 V] selected)	VDDSB RAM	VDDSB RAM ↑	2.02	2.12	2.22	V
		VDDSB RAM ↓	2.04	2.14	2.24	V
	I _{VDDSB RAM}	VDDSB RAM = 2.3 V			135	μA
ECU Standby RAM Supervision Voltage ([2.20 V - 2.43 V] selected)	VDDSB RAM	VDDSB RAM ↑	2.20	2.30	2.40	V
		VDDSB RAM ↓	2.23	2.33	2.43	V
	I _{VDDSB RAM}	VDDSB RAM = 2.5 V			145	μA
ECU Standby RAM Supervision Voltage ([2.41 V - 2.64 V] selected)	VDDSB RAM	VDDSB RAM ↑	2.41	2.51	2.61	V
		VDDSB RAM ↓	2.44	2.54	2.64	V
	I _{VDDSB RAM}	VDDSB RAM = 2.7 V			155	μA
ECU Standby RAM Supervision Voltage ([2.66 V - 2.88 V] selected)	VDDSB RAM	VDDSB RAM ↑	2.66	2.76	2.86	V
		VDDSB RAM ↓	2.68	2.78	2.88	V
	I _{VDDSB RAM}	VDDSB RAM = 3.0 V			175	μA
ECU Standby RAM Supervision Voltage ([2.90 V - 3.13 V] selected)	VDDSB RAM	VDDSB RAM ↑	2.90	3.00	3.10	V
		VDDSB RAM ↓	2.93	3.03	3.1	V
	I _{VDDSB RAM}	VDDSB RAM = 3.2 V			185	μA
ECU Standby RAM Output Voltage(1.3V) ²⁾	VDDSB RAM	max. 600 mA load	1.23	1.3	1.33	V
ECU Standby RAM Output Voltage(1.5V) ²⁾	VDDSB RAM	max. 600 mA load	1.47	1.5	1.52	V

- 1): VDDP ↑: ECU Power Supply off → ECU Power Supply on
VDDP ↓: ECU Power Supply on → ECU Power Supply off
VDDSB RAM ↑: ECU Standby RAM Power off → ECU Standby RAM Power on
VDDSB RAM ↓: ECU Standby RAM Power on → ECU Standby RAM Power off
2): Current drawn from XETK VDDSB RAM supply must not exceed 600 mA

7.9.2 ECU Interface Connector CON6

Signal	Pin Type	V_{OH} (min) [V]	V_{OH} (max) [V]	V_{IL} (max) [V]	V_{IH} (min) [V]	V_{IH} (max) [V]	Leakage current [μ A]	Additional Load by XETK (typ) [pF] ¹⁾
TDI, /TRST	0	2.2	3.3	-	-	-	+/-44	12
TMS, TCK	0	2.2	3.3	-	-	-	+/-44	12
TDO	I			0.8	2	5.5	+/-44	12
/PORST	I ⁵⁾	-	-	0.8	2	5.5	+/-3	10
Reserved0	I	-	-	0.8	2	5.5	+/-3	10
/WDGDIS	0	-	-	-	-	5.5	+/-22	6

1) Adapter cable and Samtec connector not considered; PCB 1 pF/cm

2) max

3) min

4) Open Drain FET; $I_{Dmax} = 500 \mu$ A

5) Open Drain FET; $I_{Dmax} = 0.2$ A

7.9.3 Interface and Power Supply Connector CON7

Signal	Pin Type	V_{OH} (min) [V]	V_{OH} (max) [V]	V_{IL} (max) [V]	V_{IH} (min) [V]	V_{IH} (max) [V]	Leakage current [μ A]	Additional Load by XETK (typ) [pF] ¹⁾
DAI1	I ²⁾	-	-	0.8	2.0	5.5	+/-28	46
DAI2	I ²⁾			0.8	2.0	5.5	+/-3	10
/HDRST	I	-	-	0.8	2.0	5.5	+/-3	10

1) Adapter cable and JST connector not considered; PCB 1 pF/cm

2) Open Drain FET; $I_{Dmax} = 500 \mu$ A

7.10 Pin Assignment

7.10.1 ECU Interface Connector CON6

Pin	Signal	Direction	Comment
A1	/TRST	Out	JTAG signal
A2	TCK	Out	JTAG signal
A3	/BRKOUT	In	Debugger break signal
A4	TDI	Out	JTAG signal
A5	TDO	In	JTAG signal
A6	/WDGDIS	Out	Watchdog disable signal
B1	/BRKIN	Out	Debugger break signal
B2	GND		Signal Ground
B3	TMS	Out	JTAG signal
B4	/PORST	Out	ECU Reset signal (open drain) for Reset assertion Switched Pull-Down, 5V tolerant
B5	VDDP (Sense)	In	Comparator Input Switched power supply of ECU (ignition)
B6	Reserved		Reserved

7.10.2 Interface and Power Supply Connector CON7

Pin	Signal	Direction	Comment
1	UBATT	In	Power supply (permanent)
2	CAL Wakeup	Out	Wakeup functionality (12 V output) ¹⁾
3	GND	-	Ground
4	VDDSBAM, opt. SENSE	Out	Backup voltage (1.3 V) of ECU standby RAM provided by the XETK, optional additional sense ²⁾
5	/HDRST	In	ECU reset signal for reset detection
6	DAI1, opt. SENSE	Bidir	GPIO pin for startup communication and triggering, optional additional sense ³⁾
7	DAI2	Bidir	GPIO pin for startup communication and triggering

¹⁾: if not implemented, do not connect

²⁾: SENSE: Pin 4 configured to supply and sense the VDDSBAM voltage

³⁾: SENSE: Pin 4 or pin 6 configured to supervise ECU standby RAM by the XETK to detect data consistency

7.11 Mechanical Dimensions

The reference measure for all drawings is millimeters. The reference measure for all drawings is millimeters.




Fig. 7-2 XETK-S4.2 Dimensions - Top View

Item	Dimension [Millimeters]	Tolerance [Millimeters]	Dimension [Inches]	Tolerance [Inches]
A	60.00	+/- 0.20	2.362	+/- 0.008
B	56.50	+/- 0.20	2.224	+/- 0.008
C	3.50	+/- 0.10	0.138	+/- 0.004
D	3.25	+/- 0.10	0.128	+/- 0.004
E	37.25	+/- 0.20	1.466	+/- 0.008
F	40.25	+/- 0.20	1.585	+/- 0.008
H	2.60	+/- 0.20	0.102	+/- 0.008





Fig. 7-3 XETK-S4.2 Dimensions - Side View

Item	Dimension [Millimeters]	Tolerance [Millimeters]	Dimension [Inches]	Tolerance [Inches]
A	3.00	+/- 0.20	0.118	+/- 0.008
B	1.57	+/- 0.16	0.062	+/- 0.006
C	6.12	+/- 0.10	0.241	+/- 0.004

8 Cables and Accessories

The “Cables and Accessories” chapter contains an overview of the available cables and accessories.

8.1 ECU Adapter Cable

 **NOTE**

The screws for mounting ECU adapter cables are not included in the cable delivery, they need to be ordered separately. For detailed information on mounting accessories contact ETAS technical support.

8.1.1 CBAM230.1 Adapter Cable




Fig. 8-1 CBAM230.1 Adapter Cable

XETK ECU Adapter Cable, 100 MBit/s, suitable for ECU flush mounting (M12), 0.38 m length, shield connected to socket. Usable for ECUs with shielded housing.

Product	Length	Order Number
CBAM230.1-0m38	0.38 m	F 00K 105 791

8.1.2 CBAM240.1 Adapter Cable




Fig. 8-2 CBAM240.1 Adapter Cable

XETK ECU Adapter Cable, 100 MBit/s, shield connected to ECU-housing (lead-through diameter for cable: 10 mm), 0.6 m length, shield bare for cable gland, isolated to the XETK. Usable for ECUs with shielded housing.

Product	Length	Order Number
CBAM240.1-0m6	0.6 m	F 00K 105 792

8.2 PC Interface Cable

8.2.1 CBE200-3 Cable



Fig. 8-3 CBE200-3 Cable

Product	Length	Order Number
CBE200-3	3 m	F 00K 104 373

8.2.2 CBAE200.2 Adapter Cable




Fig. 8-4 CBAE200.2 Adapter Cable

Cable adapter to connect CBE230 cable to the PC over an RJ45 connector. The CBAE200.2-1m20 supports Gigabit Ethernet.

Product	Length	Order Number
CBAE200.2-1m20	1.20 m	F 00K 105 760

8.3 ETAS Module Interface Adapter Cable

8.3.1 CBE230.1 Cable




Fig. 8-5 CBE230.1 Cable

Gigabit Ethernet connection cable for ETAS devices. IP67 rated Lemo connectors on both sides. Gigabit Ethernet cable with power supply.

Product	Length	Order Number
CBE230.1-3	3 m	F 00K 105 757
CBE230.1-8	8 m	F 00K 105 758

8.3.2 CBAE330.2 Adapter Cable




Fig. 8-6 CBAE330.2 Adapter Cable

Gigabit to 100 MBit/s Ethernet Adapter for connection of CBE230 to ES600.

Cable adapter to connect CBE230 cable with the ES600. Power supply over the CBAE330.2 cable adapter is not supported.

Product	Length	Order Number
CBAE330.2-0m5	0.5 m	F 00K 105 759

8.4 Power Supply Cables

8.4.1 Cable K70




Fig. 8-7 Power Supply Cable K70

Dim	Millimeters	Inches
A	2000	78.74

8.4.2 Cable KA50




Fig. 8-8 Power Supply Cable KA50

Dim	Millimeters	Inches
A	200	7.87
B	50	1.97

8.5 ECU Interface Adapters

8.5.1 XETK - ECU Adapter ETAI4




Fig. 8-9 XETK - ECU Adapter ETAI4

Dim	Millimeters	Inches
A	100.00	3.94

NOTE
See Fig. 5-2 on page 26 for details on mating connector to the ETAI4

8.5.2 XETK - ECU Adapter ETAI8




Fig. 8-10 XETK - ECU Adapter ETAI8

Dim	Millimeters	Inches
A	100.0	3.94

NOTE
See Fig. 5-2 on page 26 for details on mating connector to the ETAI8

9 Ordering Information

9.1 XETK-S4.2

Order Name	Short Name	Order Number
Emulator Probe for the Infineon AUDDO-F, AUDDO-NG or AUDDO-MAX microprocessor, ECU adaptation via 12 pin Erni and 7 pin JST plug	XETK-S4.2	F 00K 107 758

Package Contents

- XETK-S4.2 Emulator Probe for the Infineon AURIX microprocessor family
- List "Content of this Package"
- ETK Safety Advice
- China-RoHS-leaflet_Compact_cn

9.2 XETK - ECU Adapter

Order Name	Short Name	Order Number
ETA14 XETK ECU Adapter, Erni-12 to Erni-12- Samtec (12fc - 12fc), 0m10	ETA14	F00K 106 491
ETA18 XETK ECU Adapter, JST PHR - 7 to - JST PHR - 7(7fc - 7fc), 0m10	ETA18	F00K 107 757

9.3 Power Supply

Order Name	Short Name	Order Number
Isolated Power Supply Interface for XETK	ETP2	F 00K 104 010

9.4 Cables

Please contact your local ETAS representative for further cable information.



NOTE

The cables showed in chapter "Cables and Accessories" on page 42 are not included in the XETK-S4.2 delivery.

9.4.1 ECU Adapter Cables

NOTE

The screws for mounting ECU adapter cables are not included in the cable delivery, they need to be ordered separately. For detailed information on mounting accessories contact ETAS technical support.

Order Name	Short Name	Order Number
XETK ECU Adapter Cable, 100 Mbit/s, Shield on ECU-Housing, Lemo 1B HME - JST PHE (10fc-5fc), 0m38	CBAM230.1-0m38	F 00K 105 791
XETK ECU Adapter cable, 100 MBit/s, Lemo 1B HME - JST PHE (10fc-5fc), 0m6	CBAM240.1-0m6	F 00K 105 792

9.4.2 Ethernet Cables

9.4.2.1 PC Interface Cable

Order Name	Short Name	Order Number
Ethernet PC Connection Cable 1Gbit/s, Lemo 1B FGE - RJ45 (10mc-8mc), 3 m	CBE200-3	F 00K 104 373
Ethernet Connection Adapter Cable 1 GBit/s, Lemo 1B PHE - RJ45 (10fc-8mc), 1m2	CBAE200-1m20	F 00K 105 760

9.4.2.2 ES600 / ES910 Interface Cable

Order Name	Short Name	Order Number
Ethernet Connection Cable 1 GBit/s, Lemo 1B FGE - Lemo 1B FGE (10mc- 10mc), 3 m	CBE230.1-3	F 00K 105 757
Ethernet Connection Cable 1 GBit/s, Lemo 1B FGE - Lemo 1B FGE (10mc- 10mc), 8 m	CBE230.1-8	F 00K 105 758

9.4.2.3 ES600 Interface Adapter Cable

Order Name	Short Name	Order Number
Ethernet Connection Adapter Cable 1 GBit/s to 100 MBit/s, Lemo 1B PHE - Lemo 1B FGF (10fc-8mc), 0m5	CBAE330.2-0m5	F 00K 105 759

9.4.3 Power Supply Cables

Order Name	Short Name	Order Number
External Power Supply Cable for XETKs, Lemo 0B FGG - open wires (2fc-1c), 2 m	K70	Y 261 A24 942
XETK Power Supply Cable for External Supply, with Filter Coil, Lemo 0B EGG - open wire (2fc-1c), 0m2	KA50	F 00K 000 940

10 Contact Information

ETAS Headquarters

ETAS GmbH

Borsigstraße 24
70469 Stuttgart
Germany

Phone: +49 711 3423-0
Fax: +49 711 3423-2106
Internet: www.etas.com

ETAS Subsidiaries and Technical Support

For details of your local sales office as well as your local technical support team and product hotlines, take a look at the ETAS website:

ETAS subsidiaries Internet: www.etas.com/en/contact.php
ETAS technical support Internet: www.etas.com/en/hotlines.php

Figures

Fig. 2-1	Adhesive Label (Example: Label for XETK-S14.0)	11
Fig. 2-2	WEEE-Symbol	12
Fig. 3-1	XETK-S4.2	14
Fig. 4-1	XETK-S4.2 Architecture	16
Fig. 4-2	Location of the ECU Interfaces	17
Fig. 4-3	Location of the XETK Ethernet Interface connector (CON5)	18
Fig. 4-4	Location of the XETK-S4.2 Power Supply Connectors	19
Fig. 4-5	Status LEDs of the XETK-S4.2	20
Fig. 4-6	Equivalent Circuitry of the ECU JTAG Interface (ECU)	22
Fig. 5-1	XETK-S4.2 Connection to the ECU	25
Fig. 5-2	XETK-S4.2C Connection to the ECU and to the Debugger	26
Fig. 5-3	Wiring - XETK Ethernet Interface	26
Fig. 5-4	Permanent Power Supply inside ECU available	27
Fig. 5-5	Permanent Power Supply inside ECU not available	27
Fig. 5-6	Isolated Power Supply inside ECU	27
Fig. 7-1	XETK-S4.2 JTAG Timing Diagram (40 MHz)	35
Fig. 7-2	XETK-S4.2 Dimensions - Top View	41
Fig. 7-3	XETK-S4.2 Dimensions - Side View	41
Fig. 8-1	CBAM230.1 Adapter Cable	42
Fig. 8-2	CBAM240.1 Adapter Cable	42
Fig. 8-3	CBE200-3 Cable	43
Fig. 8-4	CBAE200.2 Adapter Cable	43
Fig. 8-5	CBE230.1 Cable	43
Fig. 8-6	CBAE330.2 Adapter Cable	43
Fig. 8-7	Power Supply Cable K70	44
Fig. 8-8	Power Supply Cable KA50	44
Fig. 8-9	XETK - ECU Adapter ETAI4	45
Fig. 8-10	XETK - ECU Adapter ETAI8	45

Index

A		O	
Adapters	45	Ordering Information	46
Applications	14	P	
Architecture	16	PC Interface Cable	43
B		PC network adapter	30
Blockdiagram	16	Pin Assignment	40
C		Power Supply	19, 27, 46
Cable		Power Supply Cables	47
Interface	42	Power Supply Connector	19
Power Supply	44	Product	
CBAE200.1 Adapter Cable	43	Exclusion of liability	8
CBAE330.1 Adapter Cable	43	Product Back	12
CBAM230.1 Adapter Cable	42	R	
CBAM240.1 Adapter Cable	42	REACH regulation (EU)	13
CBE200-3 Cable	43	Recycling	12
CBE200-x Cable	43	Reset	24
CBE230.1 Cable	43	RoHS conformity	
Configuration	32	China	13
Configuration Parameter	29	European Union	13
D		S	
Data Emulation	21	Safety precautions	8
Data Emulation Memory	31	Software Support	31
Data Measurement	21	Status LED	20
Documentation	8	System Requirements	30
E		T	
ECU Interface	17	Test Characteristics	34
ECU Interface Characteristics	36	U	
ECU Voltage Supervisor	19	UKCA conformity	12
Electrical Characteristics	36	Use, intended	8
Environmental Conditions	32	V	
Ethernet Interface	18	Voltage Supervisor	19
ETK Configuration	28	W	
F		Waste Electrical and Electronic Equipment	
Features	15		12
H		WEEE	12
Hardware Description	16	WEEE take-back system	12
I		X	
Identifications on the product	11	XETK Ethernet Interface	18
Interface			
ECU	17		
Interface Cables	42		
Introduction	14		
Isolated Power Supply	27		
J			
JTAG Interface	22		
L			
LED	20		
M			
Measurement Data Memory	31		
Mechanical Dimension	41		