



## Question:

---

MDA V8.x 에서 Pi(3.141592...) 만들어 활용하는 방법이 있나요?




## Answer:

---

현재 버전에서 활용하실 수 있는 방법을 안내해 드립니다.

1. Calculated Signal 의 Toolbox 에서 Absolute:abs()값을 선택
2. Formula definition 에 이를 drag & drop 하여 함수 정의
3. 괄호 안의 공간에 3.14159265358987 을 입력
4. 이름 정의(i.e. Pi) 및 저장
5. 다른 Calculated Signal 정의 시, 이를 drag & drop 으로 활용



**Instrument Box** x **Configuration Manager** x **Calculated Signals** x

**Calculated Signals**

+ ✎ ✖

average\_PI

PI

**Toolbox**

**Absolute: abs()**

Accumulate\_Prefix\_Integral: Accumulate\_Prefix\_

Accumulate\_Prefix\_Maximum: Accumulate\_Pref

Accumulate\_Prefix\_Minimum: Accumulate\_Prefi

Accumulate\_Prefix\_Sum: Accumulate\_Prefix\_Sur

Accumulate\_Reset\_Maximum: Accumulate\_Rese

Accumulate\_Reset\_Minimum: Accumulate\_Rese

Accumulate\_Rolling\_Add: Accumulate\_Rolling\_

Accumulate\_Rolling\_Average: Accumulate\_Rollir

Accumulate\_Rolling\_Integral: Accumulate\_Rollir

...

**Help:** [f\(x\) Absolute](#)

**Absolute value.**

Name: PI Unit:

Formula Definition:

abs(3.14159265358987)

**Rate & Type**

Rate

Combined Raster (Merge Rasters)

Fixed


100 ms

Same as Signal

Type

Automatic

Description:



## Additional information:

향후에는 MDA v7 에서와 같이, Constant 항목으로 바로 보실 수 있도록 업데이트가 될 것으로 예상됩니다.



## In case of further questions:



DRIVING EMBEDDED EXCELLENCE

Please feel free to contact our Support Center, if you have further questions.  
Here you can find all information: <http://www.etas.com/en/hotlines.php>

This information (here referred to as „FAQ“) is provided without any (express or implied) warranty, guarantee or commitment regarding completeness or accuracy. Except in cases of willful damage, ETAS shall not be liable for losses and damages which may occur or result from the use of this information (including indirect, special or consequential damages).