

How to get at the address of a variable in INTECRIO




Question:

- How to get at the address of a variable in INTECRIO
- Where can I see the address of a local variable
- At which address is a certain signal stored




Answer:

- The address information is available on tab **Signals**
- Example:
 - In **INTECRIO**: In **Workspace** view > **Hardware** > **Hardware Systems** > **ES900 : ES900** > **ES910 : ES 910 (E-Target)**: Click with right mouse button on **ETK_Bypass** > **Open...**



- In dialog **ETK_Bypass**: In panel **Raster** > Click on raster
- In panel **Available Signals**: Drag and drop the according signal to panel **Selected Signals**



- Switch to tab **Signals** > In column **Name**: Look for the selected signal > In column **Signal Address**: see the address

	Device	Group	Direction	Name	Signal Type	Unit	Formula	Min	Max	Init Value	Signal Data Type	Signal Address [hex]
1	ETK_Bypass	Measure_R01	receive	Active_B_01	disc		f(phys) :=			0	uint8	0x3F8092



Do you still have questions?

- You will find further FAQ here: www.etas.com/en/faq
- Please feel free to contact our Support Center, if you have further questions.
- Here you can find all information: <http://www.etas.com/en/hotlines.php>

This information (here referred to as „FAQ“) is provided without any (express or implied) warranty, guarantee or commitment regarding completeness or accuracy. Except in cases of willful damage, ETAS shall not be liable for losses and damages which may occur or result from the use of this information (including indirect, special or consequential damages).